



## PRE-JOBSITE CHECKLIST

### Recommended for TPR 2 water based fire barrier coatings

- Correct spray tips –
  - LTX 521 - 525 (TB coating),
  - LTX 517 – 521 (IB coating).
- Airless sprayer with minimum .75 gpm
- Graco #241705 HD Texture gun
- Electrical power and at minimum 12-gauge extension cord
- 1 clean, empty 5-gallon pail for screening into
- Door screen for screening old/partial coating
- 30 mesh machine & gun (if applicable) filters
- Power drill & mixer of appropriate size
- Large cardboard sheets for prep, spray testing and cleanup
- Drop cloths or poly sheeting
- Disposable gloves, mask, protective eyewear
- 3M 6300(or equiv.) NIOSH charcoal mask
- Clean metal flashing or equivalent for spray thickness Q-Panels
- Clean Wet film gauge
- Drum heater or electric heating pads (for 5 gal pails)
- Portable fans to speed drying
- Space heaters as required to create conditioned space (=>60°f)
- Hand tools for hose leaks, etc.
- Disposable paint brushes (plastic handles best to bend brush) for back brush areas
- 90 degree swivels and paint wand extensions as required
- Work lights for tight areas
- Scaffolding (as required)
- Caliper for measuring dried sprayed Q-panels (or clean metal flashing)
- Permanent markers to mark Q-panels (or clean metal flashing) and foam spots needing touchup
- Clean-up rags
- 2 five gallon pails for clean-up
- 5 gallons of water for clean-up, warm if available
- Dish detergent for clean-up 1-2 oz.
- Antifreeze solution for final rinse and storage in sprayer